




ThinkPad Z Series Haptic Touchpad Settings



- There are 2 ways to get to the Haptic Touchpad settings menu:
- Double tap the TrackPoint to launch the Quick Menu(1)
 - Click **ADVANCED SETTINGS** to launch the Elan Touchpad menu(1a)
 - Here you can adjust the amount of force needed on the Touchpad surface
 - From the Elan Touchpad menu(1a), you can click **Touchpad** under Related settings to launch Touchpad settings(3), where you can adjust feedback intensity / sound and other features
 - You can also reach Touchpad settings(3) directly from the Windows settings menu by clicking on **Bluetooth & devices**(2) > Touchpad
 - Elan Touchpad menu(1a) can then be reached by clicking **Settings** at bottom

